



INSTALLATION:

1. Use the lint-free cloth to thoroughly clean the screen.
2. Pull tab to begin peeling liner away from film to expose adhesive.
3. Apply screen protector by positioning film, adhesive side down, on the screen.
4. Use a credit card to squeegee film in place as you continue to pull liner down.
5. Pull tab labeled front away to expose front of screen protector.

medgestore.com